

#### 12V LED PATH LIGHT

Rated Voltage 12V AC/DC

Thank you for purchasing this quality product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this product. Please keep instructions for future reference.

NOTE: This installation instruction applies to the 12V side of the luminaire only.

This luminaire is 12V extra-low voltage and can be DIY.

Do not plug this luminaire directly into 240V.

## Warranty

- This luminaire is covered by a 5 year warranty. The warranty is from date of purchase, not the date of installation. Please retain proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void warranty.

#### Important: Please Read Before Installation


- INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS Lighted lamp is HOT! WARNING To reduce the risk of FIRE OR INJURY TO PERSONS.
  - 1. Turn off/unplug and allow to cool before replacing lamp.
  - 2. Lamp gets HOT quickly! Contact only switch/plug when turning on.
  - 3. Do not touch the hot lens, guard or enclosure.
  - 4. Keep lamp away from materials that may burn.
  - 5. Do not touch lamp at any time. Use a soft cloth. Oil from skin may damage lamp.
  - 6. Do not operate the luminaire fitting with a missing or damaged shield.

SAVE THESE INSTRUCTIONS

## **Package Contents**

- A. (1) Fixture
- B. (1)Stake


## **Product Dimensions**



# Installation Instructions




# 1 Install Stake



Determine the desired location for mounting the luminaire. Hammer the stake into the ground until flange of stake is flush to grade. To avoid damage to the stake, place a board on top of the stake while hammering.


NOTE:If the ground is hard and the stake is difficult to install, make a crosscut in the ground using a flat shovel.

## 2 Install Luminaire to Stake



Clear away an area in the ground at the wireway slot on top of the stake. Lay the luminaire pigtail into the wireway slot and screw the stem onto the stake. If the fixture does not look straight, adjust by pushing or pulling on the stake only.

# 3 Wire Connections



Strip both leads from the luminaire pigtail. Using two wire connectors (sold separately), connect the leads from the luminaire to the main low voltage supply cable leads.